

GROUND-WATER SAMPLING GUIDELINES FOR SUPERFUND AND RCRA PROJECT MANAGERS

The Ground Water and Engineering Forums were established by professionals from the United States Environmental Protection Agency (USEPA) in the ten USEPA Regional Offices. The Forums are committed to the identification and resolution of scientific, technical and engineering issues impacting the remediation of Superfund and RCRA sites. The Forums are supported by and advise OSWER's Technical Support Project, which has established Technical Support Centers in laboratories operated by the Office of Research and Development, Office of Radiation Programs, and the Environmental Response Team. The Centers work closely with the Forums providing state-of-the-science technical assistance to USEPA project managers.

This document provides sampling guidelines primarily for ground-water monitoring wells which have a screen or open interval with a length of ten feet or less which can accept a sampling device. Procedures that minimize disturbance to the aquifer will yield the most representative ground-water samples. This document provides a summary of current and/or recommended ground-water sampling procedures. This document was developed by the Superfund/RCRA Ground Water Forum and incorporates comments from ORD, Regional Superfund hydrogeologists and others. These guidelines are applicable to the great majority of sites, but are not intended to replace or supersede regional and/or project-specific sampling plans. These guidelines are intended to assist in developing sampling plans using the project-specific goals and objectives. However, unusual and/or site-specific circumstances may require approaches other than those specified in this document. In these instances, the appropriate Regional hydrologists/geologists should be contacted to establish alternative protocols.

INTRODUCTION

The goal of ground-water sampling is to collect samples which are "representative" of in-situ ground-water conditions and to minimize changes in ground-water chemistry during sample collection and handling. Experience has shown that ground-water

sample collection and handling procedures can be a source of variability in water-quality concentrations due to differences in sampling personnel, sampling procedures, and equipment (U.S. Environmental Protection Agency, 1995).

Several different ground-water sampling procedures can be used, which vary primarily through the criteria used to determine when a sample is representative of ground-water conditions. No single method or procedure is universally applicable to all types of ground-water-sampling programs, therefore, consideration should be given to a variety of factors when determining which method is best suited to site-specific conditions. These site-specific conditions include sampling objectives, equipment availability, and site location and physical constraints. This paper will discuss each of these conditions and how they may contribute to the decision process in choosing the appropriate sampling methodology and equipment to be used during ground-water sampling.

This paper focuses on ground-water sampling procedures for monitoring wells only where separate, free-phase, Non-Aqueous Phase Liquids (NAPLs) are not present in the monitoring well. Residential and/or municipal-production wells where special sampling procedures and considerations need to be implemented are not discussed in this document. The recommendations made in this paper are based on findings presented in the current literature, and will be subject to revision as the understanding of ground-water-sampling procedures increases.

SAMPLING OBJECTIVES

The objective of a good sampling program should be the collection of a "representative" sample of the current ground-water conditions over a known or specified volume of aquifer. Ideally to meet this objective, sampling equipment, sampling method, monitoring well construction, monitoring well operation and maintenance, and sample handling procedures should not alter the chemistry of the sample. A sample that is obtained from a poorly constructed well, or using improper sampling equipment, or using poor sampling techniques, or preserved improperly, can bias the sampling results. Unrepresentative samples can lead to misinterpretations of ground-water-quality data. Generally, the costs of obtaining representative ground-water samples are insignificant when compared to potential remedial responses that

may be implemented based on erroneous data or when considering the overall monitoring program costs over the life of the program (Nielson, 1991).

The data quality objectives (DQO's) of the sampling program should be thoroughly developed, presented and understood by all parties involved. To develop the DQO's, the purpose of the sampling effort and data use(s) should be clearly defined. The sampling guidelines presented here can be used for a variety of monitoring programs, these include site assessment, contaminant detection, site characterization, remediation, corrective action and compliance monitoring.

For example DQO's for a site characterization sampling effort might vary from those of a remediation monitoring sampling effort. This difference could be in how much of the screen interval should be sampled. A site characterization objective may be to collect a sample that represents a composite of the entire (or as close as is possible) screened interval of the monitoring well. On the other hand, the monitoring objective of a remediation monitoring program may be to obtain a sample that represents a specific portion of the screened interval.

Additionally, the site characterization may require analyses for a broad suite of contaminants whereas, the remediation monitoring program may require fewer contaminants to be sampled. These differences may dictate the type of sampling equipment used, the type of information collected and the sampling protocol.

In order to develop applicable DQO's, a site conceptual model should be developed. The site conceptual model should be a dynamic model which is constantly revised as new information is collected and processed. The conceptual model, as it applies to the DQO's, should focus on contaminant fate and transport processes, such as contaminant pathways, how the geologic materials control the contaminant pathways (depositional environments, geologic structure, lithology, etc.), types of contaminants present (hydrophobic versus hydrophilic for example), and the processes that influence concentrations of the contaminants present such as dilution, biodegradation, dispersion. The detail of the conceptual model will depend greatly on the availability of information, such as the number of borings/monitoring wells and the amount of existing analytical data. Clearly, a site that is being investigated for the first time will have a much simpler conceptual model compared to a site

that has had a Remedial Investigation, Feasibility Study, and Remedial Design, (or, within the RCRA Program, a RCRA Facility Assessment, a RCRA Facility Investigation, and a Corrective Measures Study), and is currently in remediation/corrective action monitoring. Specific parameters that a conceptual model should describe that may impact the design of a ground-water-sampling program include:

- a) The thickness, lateral extent, vertical and horizontal flow direction, and hydraulic conductivity contrasts of the geologic materials controlling contaminant transport from the site (thick units versus thin beds versus fractures, etc.)
- b) The types of contaminants to be sampled (volatile organic compounds, semi-volatile organic compounds, metals, etc.) and factors that could bias sampling results (turbidity for metals, co-solvation effects on PCB's, etc.)
- c) Lateral and vertical distribution of contamination (contaminants distributed throughout an entire unit being monitored versus localized distribution controlled by small scale features, etc.)

Vertical aquifer characterization is strongly recommended prior to the completion of a ground-water monitoring well installation program. A detailed vertical aquifer characterization program should include field characterization of hydraulic conductivities, determination of vertical and horizontal flow directions, assessment of lithologic and geologic variations, and determination of vertical and horizontal contaminant distributions. The successful completion of a vertical aquifer characterization program provides detailed information to guide the technical and cost-effective placement, vertically and aerially, of monitoring wells.

INFORMATION NEEDED PRIOR TO SAMPLING

To ensure appropriate methodology and expedient collection of water-quality samples, information is needed before a sample is collected. Some information should be obtained prior to the start of field activities such as well condition, construction, water-level information, contaminant types and concentrations, and direction(s) of ground-water flow. Field measurements, such as depth to water and total well depth also will need to be taken prior to purging. Before commencement of all field activities, the field health and safety plan should be consulted under the

direction of the site health and safety officer.

BACKGROUND DATA

Well construction and maintenance information are needed to better plan the sampling program, optimize personnel and obtain more representative samples. Prior to field activities, personnel should have specific information including: well casing diameter, diameter of the borehole, type of casing material, lock number and keys, physical access to wells, length of and depth to well screen. The diameter of each well casing is used to select the correct equipment and technique for purging and sampling the well. A site map with possible physical barriers and description of access is necessary to allow for the selection of proper equipment based on several factors, such as: portability, ease of repair, power sources, containment of purge water and well accessibility. The length and depth of each well screen and depth to water is important when placing a sampling device's intake at the proper depth for purging and sampling and for choosing a sampling device. Well development information is needed to ensure that purging and sampling rates will not exceed well development extraction rates. Previous sampling information should be provided and evaluated to determine the nature and concentrations of expected contaminants. This will be useful in determining the appropriate sampling methodology and quality assurance/quality control (QA/QC) samples (for example, field duplicates, equipment blanks, trip blanks). An example of a sampling checklist for field personnel is given in Attachment 1. This information should be kept in the field for easy access during sampling activities.

When evaluating previous sampling information, consideration should be given to the amount of time that has expired between the last sampling effort and the planned sampling effort. If this time exceeds one year, the need for redevelopment of the monitoring wells should be evaluated. The necessity of redevelopment can be evaluated by measuring total depth of well and comparing to well construction logs. If the depth measurement indicates siltation of the monitoring well screen, or evidence exists that the well screen is clogged, the well should be redeveloped prior to sampling. The assessment of the condition of the monitoring wells should be completed several weeks prior to commencement of sampling activities, in order to allow the proper recovery of the developed wells prior to sampling. This is especially important in wells where prior

sampling has indicated high turbidity. The time for a well to re-stabilize after development is dependent on site-specific geology and should be specified in the site sampling plan. The development method, if necessary, should be consistent with the sampling objectives, best technical criteria and USEPA guidelines (Aller et al., 1991; Izraeli et al., 1992; Lapham et al., 1997).

REFERENCE POINT

Each well should be clearly marked with a well identifier on the outside and inside of the well casing. Additionally, each well should have a permanent, easily identified reference point from which all depth measurements are taken. The reference point (the top of the inner casing, outer casing, or security/protective casing) should remain constant through all measurements, should be clearly marked on the casing and its description recorded. Whenever possible, the inner casing is recommended as a reference point, because of the general instability of outer casings due to frost heaving, vehicular damage, and other phenomena which could cause movement of casings. The elevation of this reference point should be known and clearly marked at the well site (Nielson, 1991). This reference point should also have a known latitude and longitude that are consistent with the Regional and National Minimum Data Elements requirements. The elevation of the reference point should be surveyed relative to Mean Sea Level (MSL) using the NAVD 88 datum.

TOTAL WELL DEPTH

The depth of each well is required to calculate the volume of standing water in the well and to document the amount of siltation that may have occurred. Moreover, measuring the depth to the bottom of a well provides checks for casing integrity and for siltation of the well screen. Corrosion can cause leaking or collapse of the well casing, which could lead to erroneous or misleading water-level measurements. Corrosion, silting, and biofouling can clog well screens and result in a sluggish response or no response to water-level changes, as well as changes in ground-water chemistry. Well re-development or replacement may be needed to ensure accurate collection of a representative water-quality sample.

Total well depths should be measured and properly recorded to the nearest one-tenth of a foot using a steel tape with a weight

attached. The steel tape should be decontaminated before use in another well according to the site specific protocols. A concern is that when the steel tape and weight hit the bottom of the well, sediment present on the bottom of a well may be stirred up, thus increasing turbidity which will affect the sampling results. The frequency of total well depth measurements varies, with no consensus for all hydrogeologic conditions. The United States Geological Survey (USGS) recommends a minimum of once a year (Lapham et al., 1997), as does the USEPA (Barcelona et al., 1985). The USEPA later recommends a total well depth taken every time a water-quality is collected or a water-level reading taken (Aller et al., 1991). Therefore, when possible, the total depth measurements should be taken following the completion of sampling (Puls and Barcelona, 1996). When total-well-depth measurements are needed prior to sampling, as much time as possible should be allowed prior to sampling, such as a minimum of 24 hours. The weight of electric tapes are generally too light to determine accurate total well depth. If depth of well is greater than 200 feet, stretching of the tape must be taken into consideration.

DEPTH TO WATER

All water levels should be measured from the reference point by the use of a weighted steel tape and chalk or an electric tape (a detailed discussion of the pros and cons of the different water level devices is provided in Thornhill, 1989). The steel tape is a more accurate method to take water levels, and is recommended where shallow flow gradients (less than 0.05 foot/foot or 0.015 meter/meters) or deep wells are encountered. However, in those cases where large flow gradients or large fluctuations in water levels are expected, a calibrated electric tape is acceptable. The water level is calculated using the well's reference point minus the measured depth-to-water. At depths approximately greater than 200 feet, the water-level-measuring device should be chosen carefully, as some devices may have measurable stretching.

The depth-to-water measurement must be made in all wells to be sampled prior to activities in any single well which may change the water level, such as bailing, pumping, and hydraulic testing. All readings are to be recorded to the nearest one-hundredth of a foot.

The time and date of the measurement, point of reference, measurement method, depth-to-water level measurement, and any calculations should be properly recorded. In addition, any known, outside influences (such as: tidal cycles, nearby pumping

effects, major barometric changes) that may affect water levels should be noted.

GROUND-WATER SAMPLING METHODS

The ground-water sampling methods to be employed at a site should be dependent on site-specific conditions and requirements, such as data-quality objectives and well accessibility. Ground-water sampling methods vary based on the type of device used, the position of the sampler intake, the purge criteria used, and the composition of the ground water to be sampled (e.g., turbid, containing high volatile organics, etc.). All sampling methods and equipment should be clearly documented, including purge criteria, field readings, etc. Examples of appropriate documentation are provided in Attachment 2 of this document and Appendix E of the U.S. Environmental Protection Agency, 1995 document.

The water in the screen and filter pack is generally in a constant state of natural flux as ground water passes in and out of the well. However, water above the screened section remains relatively isolated and become stagnant. Stagnant water is subject to physio-chemical changes and may contain foreign material which can be introduced from the surface or during well construction, resulting in non-representative sample data. To safeguard against collecting a sample biased by stagnant water, specific well-purging guidelines and techniques should be followed.

A non-representative sample also can result from excessive pumping of the monitoring well. Stratification of the contaminant concentrations in the aquifer may occur, or heavier-than-water compounds may sink to the lower portions of the aquifer. Excessive pumping can dilute or increase the contaminant concentrations from what is representative of the sampling point.

PURGING AND SAMPLING DEVICES

The device used to purge and sample a well depends on the inner casing diameter, depth-to-water, volume of water in the well, accessibility of the well, and types of contaminants to be sampled. The types of equipment available for ground-water sampling include hand-operated or motor-driven suction pumps, peristaltic pumps, positive displacement pumps, submersible

pumps, various in-situ devices and bailers made of various materials, such as PVC, stainless steel and Teflon®. Some of these devices may cause volatilization and produce high pressure differentials, which could result in variability in the results of pH, dissolved oxygen concentrations, oxidation-reduction potential, specific electrical conductance, metals, volatile organics and dissolved gases. Therefore, the device chosen for well purging and sampling should be evaluated for the possible effects it may have on the chemical and physical analyses. In addition, the types of contaminants, detection levels and levels of concern as described by the site DQO's should be consulted prior to the selection of a sampling device. The same device used for purging the monitoring well should be used for sampling to minimize agitation of the water column (which can increase turbidity, increase volatilization and increase oxygen in the water).

In general, the device used for purging and sampling should not change geochemical and physical parameters and/or should not increase turbidity. For this reason, low-flow submersible or positive displacement pumps that can control flow rates, are recommended for purging wells. Dedicated sampling systems are greatly preferred since they avoid the need for decontamination of equipment and minimize turbulence in the well. If a sampling pump is used, the pump should be lowered into the well as slowly as possible and allowed to sit as long as possible, before pumping commences. This will minimize turbidity and volatilization within the well.

Sampling devices (bladders, pumps, bailers, and tubing) should be constructed of stainless steel, Teflon®, glass and other inert materials to reduce the chance of these materials altering the ground water in areas where concentrations of the site contaminants are expected to be near detection limits. The sample tubing thickness should be maximized and the tubing length should be minimized so that the loss of contaminants through the tubing walls may be reduced and the rate of stabilization of ground-water parameters is maximized. The tendency of organics to sorb into and out of many materials makes the appropriate selection of sample tubing materials critical for these trace analyses (Pohlmann and Alduino, 1992; Parker and Ranney, 1998). Existing Superfund and RCRA guidance suggest appropriate compatible materials (U.S. Environmental Protection Agency, 1992). Special material considerations are important when sampling for non-routine analyses, such as age-dating and biological constituents.

Preferably, wells should be purged and sampled using a positive-pressure pump or a low-flow submersible pump with variable controlled flow rates and constructed of chemically inert materials. If a pump cannot be used because the recovery rate is so slow (less than 0.03 to 0.05 gallons per minute or 100 to 200 milliliters per minute) and the volume of the water to be removed is minimal (less than 5 feet (1.6 meters) of water), then a bailer with a double check valve and bottom-emptying device with a control-flow check valve may be used to obtain the samples. Otherwise, a bailer should not be used when sampling for volatile organics because of the potential bias introduced during sampling (Pohlmann, et al., 1990; Yeskis, et al., 1988; Tai, et al., 1991). A peristaltic pump also may be used under these conditions, unless the bias by a negative pressure may impact the contaminant concentrations of concern (generally at depths greater than 15 to 20 feet (4.5 to 6 meters) of lift). Bailers should also be avoided when sampling for metals due to bias from increased turbidity that occurs during the deployment of the bailer which may bias inorganic and strongly hydrophobic parameters. Dedicated sampling pumps are recommended for metals sampling because the pumps avoid the generation of turbidity from frequent sampler deployment (Puls et al., 1992). A number of alternate sampling devices are becoming available, including passive diffusion samplers (Vroblesky and Hyde, 1997; Vroblesky, 2001a and b) and other in-situ sampling devices. These devices may be particularly useful to sampling low-permeability geologic materials, assuming the device is made of materials compatible with the analytical parameters, meet DQO's, and have been properly evaluated. However, the site investigator should ensure the diffusion membrane materials are selected for the COC's present at the site. Comparison tests with an approved sampling method and diffusion samplers should be completed to confirm that the method is suitable for the site.

POSITION OF SAMPLE INTAKE

Essentially there are two positions for placement of the sample pump intake, within the screen and above the screen. Each of the positions offers advantages and disadvantages with respect to the portion of the well screen sampled, data reproducibility and potential purge volumes.

When the sampling pump intake is set above the well screen, the pump generally is set just below the water level in the well. The sampling pump then is pumped until a purge criterion is

reached (commonly either stabilization of purge parameters or a set number of well volumes). If the distance between the water level and the top of the screen is long, there is concern that the water will be altered geochemically as it flows along the riser pipe, as water flows between the well screen and the sampling pump intake. This is especially a concern if the riser pipe is made of similar material as the contaminants of concern (COC) (such as a stainless steel riser with nickel as a COC, or PVC with organics as a COC). Keely and Boatang (1987) suggested that to minimize this potential influence, the sample pump be lowered gradually while purging, so that, at the time of the sampling the pump intake is just above the screen. This would minimize contact time between the ground water and the well construction materials while sampling, as well as, ensure the evacuation of the stagnant water above the screen.

With the final location of the sampling pump intake just above the well screen, the sample results may be more reproducible than those collected by positioning the pump intake within the well screen. Results may be more reproducible because the sampler can ensure that the ground water is moving into the well with the same portions of the aquifer being sampled each time assuming the same pump rate. If the pump is placed into different portions of the screen each time, different portions of the aquifer may be sampled. Of course, this can be avoided by the use of dedicated, permanently installed equipment. Additionally, the placement of the pump at the same vertical position within the screen can be ensured by the use of calibrated sampling pump hose, sounding with a weighted-tape, or using a pre-measured hose.

The placement of the pump above the screen does not guarantee the water-quality sample represents the entire well screen length. Any bias in the pump placement will be consistently towards the top of the well screen length and/or to the zone of highest hydraulic conductivity. Another possible disadvantage, or advantage, depending on the DQO's, of the placement of the pump above the well screen is that the sample may represent a composite of water quality over the well screen. This may result in dilution of a portion of the screen that is in a contaminated portion of an aquifer with another portion that is in an uncontaminated portion of the aquifer. However, shorter well screens would minimize this concern.

When the pump intake is positioned within the well screen, its location is recommended to be opposite the most contaminated zone in the well screen interval. This method is known as the low-

flow, low-stress, micropurge, millipurge, or minimal drawdown method. The well is then purged with a minimal drawdown (usually 0.33 feet (0.1 meters) based on Puls and Barcelona, 1996) until selected water-quality-indicator parameters have stabilized. Use of this method may result in the vertical portion of the sampled aquifer being smaller than the well screen length. This method is applicable primarily for short well-screen lengths (less than 5 feet (1.6 meters)) to better characterize the vertical distribution of contaminants (Puls and Barcelona, 1996). This method should not be used with longer well-screen lengths, greater than 10 feet (3 meters). By using this method, the volume of purge water can be reduced, sometimes significantly, over other purging methods.

However, two potential disadvantages of this method exist. The first potential disadvantage may involve the lower reproducibility of the sampling results. The position of the sampling pump intake may vary between sampling rounds (unless adequate precautions are taken to lower the pump into the exact position in previous sampling rounds, or a dedicated system is used), which can result in potentially different zones within the aquifer being sampled. This potential problem can be overcome by using dedicated sampling pumps and the problem may be minimized by the use of short well screens. The second potential disadvantage, or advantage, depending on the DQO's, may be that the sample which is collected may be taken from a small portion of the aquifer volume.

PURGE CRITERIA

"Low-Stress Approach"

The first method for purging a well, known as the low-stress approach, requires the use of a variable-speed, low-flow-sampling pump. This method offers the advantage that the amount of water to be containerized, treated and/or stored will be minimized. The low-stress method is based on the assumption that pumping at a low rate by a pump within the screened zone will not pull stagnant water down, as long as drawdown is minimized during pumping. Drawdown should not exceed 0.33 feet (0.1 meters) (Puls and Barcelona, 1996). The pump is turned on at a low-flow rate approximating the estimated recovery rate (based on the drawdown within the monitoring well during sampling) of the aquifer into the screen. This method requires the location of the pump intake to be within the saturated-screened interval during purging and sampling. The water-quality-indicator parameters (purge

parameters), pH, specific electrical conductance, dissolved oxygen concentration, oxidation-reduction potential, temperature and turbidity, are monitored at specific intervals. The specific intervals will depend on the volume within the tubing (include pump and flow-through-cell volumes), pump rate and drawdown; commonly every three to five minutes. These parameters should be recorded after a minimum of one tubing volume (include pump and flow-through-cell volumes) has been purged from the well. These water-quality-indicator parameters should be collected by a method or device which prevents air from contacting the sample prior to the reading, such as a flow-through-cell (Barcelona et al., 1985; Garske and Schock, 1986; Wilde et al., 1998). Once three successive readings of the water-quality-indicator parameters provided in Table 1 have stabilized, the sampling may begin. The water-quality-indicator parameters which are recommended include pH and temperature, but these are generally insensitive to indicate completion of purging since they tend to stabilize rapidly (Puls and Barcelona, 1996). Oxidation-reduction potential may not always be an appropriate stabilization parameter, and will depend on site-specific conditions. However, readings should be recorded because of its value as a double check for oxidizing conditions, and for some fate and transport issues. When possible, especially when sampling for contaminants that may be biased by the presence of turbidity, the turbidity reading is desired to stabilize at a value below 10 Nephelometric Turbidity Units (NTU's). For final dissolved oxygen measurements, if the readings are less than 1 milligram per liter, they should be collected with the spectrophotometric method (Wilde et al., 1998, Wilkin et al., 2001), colorimetric or Winkler titration (Wilkin et al., 2001). All of these water-quality-indicator parameters should be evaluated against the specifications of the accuracy and resolution of the instruments used.

During purging, water-level measurements must be taken regularly at 30-second to five minute intervals (depending on the hydraulic conductivity of the aquifer, diameter of the well and pumping rate) to document the amount of drawdown during purging. The water-level measurements will allow the sampler to control pumping rates to minimize drawdown in the well.

"Well-Volume Approach"

The second methodology for purging wells is based on proper purging of the stagnant water above the screened interval and the stabilization of water-quality-indicator parameters prior to

sampling. Several considerations in this methodology need to be evaluated before purging. For monitoring wells where the water level is above the screens, the pump should be set near the top of the water column, and slowly lowered during the purging process. For water columns within the well screen, the pump should be set at a sufficient depth below the water level where drawdown during pumping does not allow air to enter the pump. The pump should not be allowed to touch or draw sediments from the bottom of the well, especially when sampling for parameters that may be impacted by turbidity. The well-purging rate should not be great enough to produce excessive turbulence in the well, commonly no greater than one gallon per minute (3.8 liters per minute) in a 2-inch well. The pump rate during sampling should produce a smooth, constant (laminar) flow rate, and should not produce turbulence during the filling of bottles. As a result, the expected flow rate for most wells will be less than one gallon per minute (3.8 liter per minute), with expected flow rates of about one-quarter gallon per minute (500 milliliter per minute).

The stabilization criteria for a "well-volume approach" may be based on the stabilization of water-quality-indicator parameters or on a pre-determined well volume. Various research indicates that purging criteria based on water-quality-indicator parameter stabilization may not always correlate to stabilization of other parameters, such as volatile organic compounds (Gibs and Imbrigiotta, 1990; Puls et al., 1990). A more technically rigorous sampling approach, that would yield more consistent results over time would be a time-sequential sampling program at regular well-volume intervals while measuring water-quality indicator parameters. However, the cost would be prohibitive for most sites. For comparison of water-quality results, by sampling under the same conditions (same purge volume and rate, same equipment, same wells, etc.) temporal evaluations of trends may be considered.

The stabilization requirements of the water-quality-indicator parameters are consistent with those described above for the low-stress approach. The parameters should be recorded approximately every well volume and when three successive readings have reached stabilization, the sample(s) are taken (Barcelona et al., 1985). If a ground-water monitoring well has been sufficiently sampled and characterized (at least several rounds of water-quality samples obtained, including the field parameters, during several seasonal variations), and if water-quality-indicator parameters are no longer needed as a part of site characterization and/or

monitoring, then samples could be obtained based on a specific number of well volumes at the previous pumping rates.

LOW-PERMEABILITY FORMATIONS

Different procedures must be followed in the case of slow-recovery wells installed in low hydraulic conductivity aquifers. The following procedures are not optimum, but may be used to obtain a ground-water sample under less than ideal conditions. One suggested procedure is to remove the stagnant water in the casing to just above the top of the screened interval, in a well screened below the water table, to prevent the exposure of the gravel pack or formation to atmospheric conditions (McAlary and Barker, 1987). At no point should the pump be lowered into the screened interval. The pumping rate should be as low as possible for purging to minimize the drawdown in the well. However, if a well has an open interval across the water table in a low permeability zone, there may be no way to avoid pumping and/or bailing a well dry (especially in those cases with four feet of water or less in the well and at a depth to water greater than 20 to 25 feet (which is the practical limit of a peristaltic pump)). In these cases, the well may be purged dry. The sample should be taken no sooner than two hours after purging and after a sufficient volume for a water-quality sample, or sufficient recovery (commonly 90%) is present (Herzog et al., 1988). In these cases, a bailer with a double check valve with a flow-control, bottom-emptying device may be used, since many sampling pumps may have tubing capacities greater than the volume present within the well. If the depth of well and water column are shallow enough, consideration of a very low-flow device, such as a peristaltic pump, should be considered, especially if constituents are present that are not sensitive to negative pressures that may be created with the use of the peristaltic pump. If such constituents are present and sampled with a peristaltic pump, a negative bias may be introduced into the sampling results. To minimize the bias, thick-walled, non-porous tubing should be used, except for a small section in the pump heads, which require a greater degree of flexibility. As stated earlier in this paper, the DQO's for the sampling should be consulted to consider the potential impact of the sampling device on the potential bias versus the desired detection levels.

Another method to be considered for low-permeability conditions is the use of alternative sampling methods, such as passive diffusion samplers and other in-situ samplers. As more sites are characterized with these alternative sampling methods and

devices, the potential bias, if any, can be evaluated with regard to the sampling DQO's. Regional hydrologists/geologists and regional quality-assurance specialists should be consulted on the applicability of these methods for the site-specific conditions.

DECISION PROCESS FOR DETERMINING APPLICABLE SAMPLING METHODOLOGY

Once the project team has determined the sampling objectives and DQO's, reviewed the existing data, and determined the possible sampling devices that can be used, the team must decide the appropriate sampling methodology to be used. Table 2 provides a summary of considerations and rationale to be used in establishing the proper ground-water-sampling program using site-specific conditions and objectives.

POTENTIAL PROBLEMS

The primary objective is to obtain a sample representative of the ground water moving naturally (including both dissolved and particulate species) through the subsurface. A ground-water sample can be compromised by field personnel in two primary ways: taking an unrepresentative sample and incorrect handling of the (representative) sample. There are numerous ways of introducing foreign contaminants into a sample. These must be avoided by following strict sampling protocols and transportation procedures, and utilizing trained personnel. Common problems with sampling include the use of inappropriate sample containers and field composites, and the filtration of turbid samples.

SAMPLE CONTAINERS

Field samples must be transferred from the sampling equipment to the container that has been specifically prepared for that given parameter. Samples must not be composited in a common container in the field and then split in the lab. The USEPA Regional policy on sample containers should be consulted to determine the appropriate containers for the specified analysis.

TURBID SAMPLES-FIELD FILTRATION

The USEPA recognizes that in some hydrogeologic environments, even with proper well design, installation and development, in combination with the low-flow rate purging and sampling techniques, sample turbidity cannot be reduced to ambient levels.

The well construction, development and sampling information should be reviewed by the regional geologists or hydrologists to see if the source of the turbidity problems can be resolved or if alternative sampling methodologies should be employed. If the water sample is excessively turbid, the collection of both filtered and unfiltered samples, in combination with turbidity, Total Suspended Solids (TSS), Total Dissolved Solids (TDS), pumping rate and drawdown data is recommended. The filter size used to determine TSS and TDS should be the same as used in the field filtration. An in-line filter should be used to minimize contact with air to avoid precipitation of metals. The typical filter media size used is 0.45 μm because this is commonly accepted as the demarcation between dissolved and non-dissolved species. Other filter sizes may be appropriate but their use should be determined based on site-specific criteria (examples include grain-size distribution, ground-water-flow velocities, mineralogy) and project DQO's. Filter sizes up to 10.0 μm may be warranted because larger size filters may allow particulates that are mobile in ground water to pass through (Puls and Powell, 1992). The changing of filter media size may limit the comparability of the data obtained with other data sets and may affect their use in some geochemical models. Filter media size used on previous data sets from a site, region or aquifer and the data quality objectives should be taken into consideration. The filter media used during the ground-water sampling program should be collected in a suitable container and archived because potential analysis of the media may be helpful for the determination of particulate size, mineralogy, etc.

The first 500 to 1000 milliliters of ground-water sample, depending on sample turbidity, taken through the in-line filter will not be collected for a sample, in order to ensure that the filter media has equilibrated to the sample (manufacturer's recommendations also should be consulted). Because bailers have been shown to increase turbidity while purging and sampling, bailers should be avoided when sampling for trace element, metal, PCB and pesticide constituents. If portable sampling pumps are used, the pumps should be gently lowered to the sampling depth desired, carefully avoiding being lowered to the bottom of the well, and allowed to sit in order to allow any particles mobilized by pump placement to settle. Dedicated sampling equipment installed in the well prior to the commencement of the sampling activities is one of the recommended methods to reduce turbidity artifacts (Puls and Powell, 1992; Kearl et al., 1992; Puls et al., 1992; Puls and Barcelona, 1996).

SAMPLER DECONTAMINATION

The specific decontamination protocol for sampling devices is dependent on site-specific conditions, types of equipment used and the types of contaminants encountered. Once removed from the well, non-dedicated sampling equipment should be decontaminated to help ensure that there will be no cross-contamination between wells. Disposable items such as rope and low-grade tubing should be properly disposed between wells. Cleaning thoroughly that portion of the equipment that is going to come into contact with well water is especially important. In addition, a clean plastic sheet should be placed adjacent to or around the well to prevent surface soils from coming in contact with the purging and sampling equipment. The effects of cross-contamination can be minimized by sampling the least contaminated well first and progressing to the more contaminated ones. Equipment blanks should be collected on a regular basis from non-dedicated equipment, the frequency depending on the sampling plan and regional protocols, to document the effectiveness of the decontamination procedures.

The preferred method is to use dedicated sampling equipment whenever possible. Dedicated equipment should still be cleaned on a regular basis to reduce biofouling, and to minimize adsorption effects. Dedicated equipment should have equipment blanks taken after every cleaning.

POST-SAMPLING ACTIVITIES

Specific activities should be completed at monitoring wells at regular intervals to ensure the acquisition of representative ground-water samples. Activities include hydraulic conductivity testing to determine if a monitoring well needs redeveloping and/or replacing. Another activity that needs to be completed is regular surveying of well measuring points impacted by frost heaving and site activities. The schedules of these activities are to be determined on a site-by-site basis in consultation with regional geologists or hydrologists, but at a minimum, should be every five years.

CONCLUSION

This document provides a brief summary of the state-of-the-science to be used for Superfund and RCRA ground-water studies.

As additional research is completed, additional sampling experience with other sampling devices and methods and/or additional contaminants are identified, this paper may be revised to include the new information/concerns. Clearly there is no one sampling method that is applicable for all sampling objectives. As new methods and/or equipment are developed, additional standard operating procedures (SOP's) should be developed and attached to this document. These SOP's for ground-water sampling should include, at a minimum: Introduction, Scope and Application, Equipment, Purging and Sampling Procedures, Field Quality Control, Decontamination Procedures and References. Example SOP's for the low-stress/minimal-drawdown and well-volume sampling procedures have been included as Attachments 3 and 4. These example SOP's are to be considered a pattern or starting point for site-specific ground-water-sampling plans. A more detailed discussion of sampling procedures, devices, techniques, etc. is provided in various publications by the USEPA (Barcelona et al., 1985; U.S. Environmental Protection Agency, 1993) and the U.S. Geological Survey (Wilde et al., 1998).

REFERENCES

Aller, L., T.W. Bennett, G. Hackett, R.J. Petty, J.H. Lehr, H. Sedoris, D.M. Nielson and J.E. Denne, 1991, Handbook of Suggested Practices for the Design and Installation of Ground-Water Monitoring Wells; U.S. Environmental Protection Agency, EPA/600/4-89/034, 221 pp.

Barcelona, M.J., J.P. Gibb, J.A. Hellfrich and E.E. Garske, 1985, Practical Guide for Ground-Water Sampling; U.S. Environmental Protection Agency, EPA/600/2-85/104, 169 pp.

Garske, E.E., and M.R. Schock, 1986, An Inexpensive Flow-Through Cell and Measurement System for Monitoring Selected Chemical Parameters in Ground Water; Ground Water Monitoring Review, Vol. 6, No. 3, pp. 79-84.

Gibs, J. and T.E. Imbrigiotta, 1990, Well-Purging Criteria for Sampling Purgeable Organic Compounds; Ground Water, Vol. 28, No. 1, pp.68-78.

Herzog, B.L., S.J. Chou, J.R. Valkenburg and R.A. Griffin, 1988, Changes in Volatile Organic Chemical Concentrations After Purging Slowly Recovering Wells; Ground Water Monitoring Review, Vol. 8, No. 4, pp. 93-99.

Izraeli, R., D. Yeskis, M. Collins, K. Davies and B. Zavala, 1992, Monitoring Well Development Guidelines for Superfund Project Managers; U.S. Environmental Protection Agency Ground Water Forum Paper, 4 pp.

Kearl, P.M., N.E. Korte, and T.A. Cronk, 1992, Suggested Modifications to Ground Water Sampling Procedures Based on Observations from the Colloid Borescope; Ground Water Monitoring Review, Vol. 12, No. 2, pp. 155-161.

Keely, J.F. and K. Boateng, 1987, Monitoring well installation, purging, and sampling techniques - part 1: conceptualizations; Ground Water, Vol. 25, No. 4 pp. 427-439.

Lapham, W.W., F.D. Wilde and M.T. Koterba, 1997, Guidelines and Standard Procedures for Studies of Ground-Water Quality: Selection and Installation of Wells, and Supporting Documentation; U.S. Geological Survey Water-Resources Investigations Report 96-4233, 110 pp.

McAlary, T.A. and J.F. Barker, 1987, Volatilization Losses of Organics During Ground Water Sampling from Low Permeability Materials; Ground Water Monitoring Review, Vol. 7, No. 4, pp. 63-68.

Nielson, D.M., 1991, Practical Handbook of Ground-Water Monitoring; Lewis Publishers, 717 pp.

Parker, L.V. and T.A. Ranney, 1998, Sampling Trace-Level Organic Solutes with Polymeric Tubing: Part 2, Dynamic Studies; Ground Water Monitoring and Remediation, Vol. 18, No. 1, pp. 148-155.

Pohlmann, K.F., R.P. Blegen and J.W. Hess, 1990, Field Comparison of Ground-Water Sampling Devices for Hazardous Waste Sites: An Evaluation using Volatile Organic Compounds; U.S. Environmental Protection Agency, EPA/600/4-90/028, 102 pp.

Pohlmann, K.F. and A.J. Alduino, 1992, GROUND-WATER ISSUE PAPER: Potential Sources of Error in Ground-Water Sampling at Hazardous Waste Sites; U.S. Environmental Protection Agency, EPA/540/S-92/019.

Puls, R.W., J.H. Eychaner and R.M. Powell, 1990, ENVIRONMENTAL RESEARCH BRIEF: Colloidal-Facilitated Transport of Inorganic Contaminants in Ground Water: Part I. Sampling Considerations; U.S. Environmental Protection Agency, EPA/600/M-90/023, 12 pp.

Puls, R.W. and R.M. Powell, 1992, Acquisition of Representative Ground Water Quality Samples for Metals; Ground Water Monitoring Review, Vol. 12, No. 3, pp. 167-176.

Puls, R.W., D.A. Clark, B. Bledsoe, R.M. Powell and C.J. Paul, 1992, Metals in Ground Water: Sampling Artifacts and Reproducibility; Hazardous Waste and Hazardous Materials, Vol. 9, No. 2, pp. 149-162.

Puls, R.W. and M.J. Barcelona, 1996, GROUND-WATER ISSUE PAPER: Low-Flow (Minimal Drawdown) Ground-Water Sampling Procedures; U.S. Environmental Protection Agency, EPA/540/S-95/504, 12 pp.

Tai, D.Y., K.S. Turner, and L.A. Garcia, 1991, The Use of a Standpipe to Evaluate Ground Water Samples; Ground Water Monitoring Review, Vol. 11, No. 1, pp. 125-132.

Thornhill, J.T., 1989, GROUND-WATER ISSUE PAPER: Accuracy of Depth to Water Measurements; U.S. Environmental Protection Agency, EPA/540/4-89/002, 3 pp.

U.S. Environmental Protection Agency, 1992, RCRA Ground-Water Monitoring: Draft Technical Guidance; EPA/530-R-93-001.

U.S. Environmental Protection Agency, 1993, Subsurface Characterization and Monitoring Techniques: A Desk Reference Guide: Volume I: Solids and Ground Water Appendices A and B; EPA/625/R-93/003a.

U.S. Environmental Protection Agency, 1995, Ground Water Sampling - A Workshop Summary, Dallas, Texas, November 30-December 2, 1993; EPA/600/R-94/205, 146 pp.

Vroblesky, D.A., 2001a, User's guide for polyethylene-based passive diffusion bag samplers to obtain volatile organic compound concentrations in wells, Part 1: Deployment, recovery, data interpretation, and quality control and assurance; U.S. Geological Survey Water-Resources Investigations Report 01-4060, 18 pp.

Vroblesky, D.A. ed., 2001b, User's guide for polyethylene-based passive diffusion bag samplers to obtain volatile organic compound concentrations in wells, Part 2: Field Tests; U.S. Geological Survey Water-Resources Investigations Report 01-4061, variously paginated.

Vroblesky, D.A. and Hyde, W.T., 1997, Diffusion samplers as an inexpensive approach to monitoring VOCs in ground water; Ground Water Monitoring and Remediation, Vol. 17, No. 3, pp. 177-184.

Wilde, F.D., D.B. Radtke, J.Gibs and R.T. Iwatsubo, eds., 1998, National Field Manual for the Collection of Water-Quality Data; U.S. Geological Survey Techniques of Water-Resources Investigations, Book 9, Handbooks for Water-Resources Investigations, variously paginated.

Wilkin, R.T., M.S. McNeil, C.J. Adair and J.T. Wilson, 2001, Field Measurement of Dissolved Oxygen: A Comparison of Methods, Ground Water Monitoring and Remediation, Vol. 21, No. 4, pp. 124-132.

Yeskis, D., K. Chiu, S. Meyers, J. Weiss and T. Bloom, 1988, A Field Study of Various Sampling Devices and Their Effects on Volatile Organic Contaminants; Proceedings of the Second National Outdoor Action Conference on Aquifer Restoration, Ground Water Monitoring and Geophysical Methods, National Water Well Association, May 1988.

TABLE 1: Stabilization Criteria with References for Water-Quality-Indicator Parameters

Parameter	Stabilization Criteria	Reference
pH	+/- 0.1	Puls and Barcelona, 1996; Wilde et al., 1998
specific electrical conductance (SEC)	+/- 3%	Puls and Barcelona, 1996
oxidation-reduction potential (ORP)	+/- 10 millivolts	Puls and Barcelona, 1996
turbidity	+/- 10% (when turbidity is greater than 10 NTUs)	Puls and Barcelona, 1996; Wilde et al., 1998
dissolved oxygen (DO)	+/- 0.3 milligrams per liter	Wilde et al., 1998

TABLE 2: Applicability of Different Approaches for Purging and Sampling Monitoring Wells

	Low-Stress Approach	Well-Volume Approach	Others (such as passive diffusion samplers, in-situ samplers, and other non-traditional ground-water sampling pumps)
Applicable Geologic Materials¹	Materials with moderate to high hydraulic conductivities. May be applicable to some low hydraulic conductivities, if can meet minimal drawdown criteria.	Materials with low to high hydraulic conductivities	Materials with very low to high hydraulic conductivities
Aquifer/Plume Characterization Data Needs prior to Choosing Sampling Method²	High definition of vertical hydraulic conductivity distribution and vertical contaminant distribution	Plume and hydraulic conductivity distributions are less critical	May need to consider the degree of hydraulic and contaminant vertical distribution definition dependent on Data Quality Objectives and sampler type.
Constituent Types Method is Applicable	Mainly recommended for constituents which can be biased by turbidity in wells. Applicable for most other contaminants.	Applicable for all sampling parameters. However, if turbidity values are elevated, low-stress approach may be more applicable if constituents of concern are turbidity sensitive.	Constituents of concern will be dependent on the type of sampler.
Data Quality Objectives	<ol style="list-style-type: none"> 1) High resolution of plume definition both vertically and horizontally. 2) Reduce bias from other sampling methods if turbidity is of concern. 3) Target narrow sections of aquifer. 	<ol style="list-style-type: none"> 1) Basic site characterization 2) Moderate to high resolution of plume definition (will be dependent on screen length). 3) Target sample composition to represent entire screened/open interval 	<ol style="list-style-type: none"> 1) Can be applicable to basic site characterization, depending on sampler and methodology used. 2) Can reduce bias from other sampling methods. 3) May yield high resolution of plume definition.

¹Hydraulic conductivities of aquifer materials vary from low hydraulic conductivities (clays, silts, very fine sands) to high conductivities (gravels, sands, weathered bedrock zones). This term for the use on this table is subjective, and is more dependent on the drawdown induced in a monitoring well when sampled with a ground-water sampling pump. For instance, in a well being pumped at 4 liters per minute (l/min) with less than 0.1 feet of drawdown, can be considered to have high hydraulic conductivity. A well that can sustain a 0.2 to 0.4 l/min pumping rate, but has more than 0.5 feet of drawdown can be considered to have low hydraulic conductivity. To assign absolute values of hydraulic conductivities to well performance and sustainable pumping rates cannot be completed because of the many factors in monitoring well construction, such as well diameter, screen open area, and length of screen.

² See last paragraph under the SAMPLING OBJECTIVES section.

ATTACHMENT 1

Example Sampling Checklist

SAMPLING CHECKLIST

Well Identification: _____

Map of Site Included: Y or N

Wells Clearly Identified w/ Roads: Y or N

Well Construction Diagram Attached: Y or N

Well Construction:

Diameter of Borehole: _____ Diameter of Casing: _____

Casing Material: _____ Screen Material: _____

Screen Length: _____ Total Depth: _____

Approximate Depth to Water: _____

Maximum Well Development Pumping Rate: _____

Date of Last Well Development: _____

Previous Sampling Information:

Was the Well Sampled Previously: Y or N

(If Sampled, Fill Out Table Below)

Table of Previous Sampling Information				
Parameter	Previously Sampled	Number of Times Sampled	Maximum Concentration	Notes (include previous purge rates)

ATTACHMENT 2

Example Ground-Water Sampling Field Sheets

³Specific Electrical Conductance

ATTACHMENT 3

EXAMPLE STANDARD OPERATING PROCEDURE:

**Standard Operating Procedure for
Low-Stress (Low Flow)/Minimal Drawdown
Ground-Water Sample Collection**

ATTACHMENT 4

EXAMPLE STANDARD OPERATING PROCEDURE:

**Standard Operating Procedure for
the Standard/Well-Volume Method for
Collecting a Ground-Water Sample**